



ASSEMBLY INSTRUCTIONS IN SUCCESSION

1. SEAT THE BASE IN THE CHOSEN PLACE
2. PLACE THE PLATES INTO THE BASE
3. FIX THE SQUARE TUBE TO THE BASE
4. INSERT THE COLUMN INTO THE SQUARE TUBE N° 3
5. TIGHTEN THE TWO SELF-THREADED SCREWS
6. INSERT THE HEAD INTO THE COLUMN N° 4
7. FIX THE HEAD TO THE COLUMN THROUGH TWO SELF-THREADED SCREWS
8. INSERT THE FOUR HORIZONTAL POLES
9. FIX THE FOUR HORIZONTAL POLES WITH FOUR SELF-THREADED SCREWS
10. INSERT THE PARASOLS INTO THE POLES N° 8 AND FIX THEM WITH SELF-THREADED SCREWS
11. TIGHTEN THE TWO PINS M6X22
12. TIGHTEN PARTIALLY THE FOUR KNOBS
13. INSERT THE FOUR WINCHES BETWEEN THEIR INSERT, KNOB AND PIN
14. TIGHTEN THE KNOBS
15. PASS WINCHES CABLES THROUGH THE HOLES ON THE HEAD
16. HOOK THE CABLES WITH PARASOLS CABLES
17. OPEN CAREFULLY THE PARASOLS
18. FIX THE ANGULAR PLATES TO THE CENTRAL COLUMN
19. FIX THE RIB TO THE ANGULAR PLATES. BEFORE CLOSING THE PARASOL DETACH THE RIB FROM ANGULAR PLATES